



Note: The RX and TX LED indicate USB send/receive, NOT serial, so they are reversed from the datasheet here.

